SPACING

FLOORING SIZE NAIL SIZE

SPACING

3/4" THICK T&G STRIP

x 1 1/2", 2 1/4" 2" barbed flooring cleat through 3 1/4" 2" barbed flooring nail, or 2" 15 gauge staples

10"-12" apart 8"-10" apart preferred

3/4" THICK T&G PLANK

4"-8" 2" barbed flooring cleat 7d or 8d flooring nail, or

2" 15 gauge staples 8" apart with 1/2" crowns

Blind nail along the length of strip/plank and near the ends (1"-3") Minimum of 2 nails per strip/plank (Plank flooring may require face nailing

with 1/2" crowns

Follow Manufacturer's Instruction for installation of Plank Flooring. Widths 4" and over must be installed on a proper subfloor.

and/or screws for additional fastening)

NOFMA hardwood flooring must be installed over a proper subfloor.* Tongue and groove flooring is blind nailed on the tongue edge with face nailing required on starting runs (1-2) and finishing runs (2-4). Square edge flooring is face nailed.

Inadequate nailing contributes to cracks and noisy floors by allowing movement of the flooring.*(Use 1 1/2" fasteners with 3/4" plywood subfloor on a concrete slab. A concrete slab with screeds 12" o.c. does not always require a subfloor.

FLOORING SIZE 1/2" THICK T&G STRIP

x 1 1/2" & 2" 1 1/2" barbed flooring cleat, 5d screw, cut steel, 10" apart

or wire casing nail Must install over proper subfloor

NAIL SIZE

3/8" THICK T&G STRIP

x 1 1/2" & 2" 1 1/4" barbed flooring cleat, 4d bright wire 8" apart casing nail

Must install over proper subfloor

5/16" SQUARE EDGE (Not Tongue & Groove)

x 1 1/2" & 2"

1" 15 gauge fully
barbed flooring brad

2 nails every 7"

x 1 1/3"

1" 15 gauge barbed
flooring brad

1 nail every 5"
on alternate

sides of strip

Follow Manufacturer's Instructions for installing
Square Edge Flooring. Must install over a subfloor.

(Do not mix types of fasteners when blind nailing the field, except near walls where hand nailing is required.)

Information supplied courtesy of National Oak Flooring Manufacturers Ass'n P.O. Box 3009, Memphis TN 38173-0009