

MATERIAL ESTIMATOR

How to figure the tools and materials needed to build a Goof Proof Shower

Mark E. Industries, Inc.
28921 U.S. HWY 19 No.
Clearwater, FL 33761
1-866-771-9470
(727) 771-9470
www.markeindustries.com




oof proof goof proof goof proof goof proof goof proof goof proof goof proof goof proof goof proof goof proof goof proof goof proof


Constructing Your Shower Using a Linear Drain Such As Quick Drain with Noble TS Sheet Water Proofing Membrane

Note: Unlike Vinyl, Chloraloy and Roll-On Liners, Pre-Pitch will not be used in this application. Quick Pitch Extra and Extended Kits (#XFS-101.2 and #EXT-103) with Quick Clips (#QC-109) will be the tools of choice.


- 1 Determine the size and shape of your shower including the drain location.




- 2 With the roughed-in 2 x 4 curb in place, measure the distances from the drain to the wall opposite the drain. Measure the distance along the length of the drain and, starting at one end, figure by 8"-12" increments.



Note: Quick Pitch Extra Float Sticks #XFS-101.2 are 36" in length. If the distances are greater, Quick Pitch Extended Float Sticks #EXT-103 kits will be required.




- 3 After determining how many Float Sticks, both Standard and Extended necessary, you will need 2 Quick Clips (#QC-109) for every 36" run.




QC-109 Quick Clip

- 4 To determine the quantity of Kirb Perfect (#543) sections needed, measure in 30" increments. Curb sections are 30" and have dove tail connectors to attach to one another and will accommodate all lengths and angles.



- 5 To figure the liner size (Noble TS Sheet Water Proofing) measure the shower compartment length and width and add 6" or what is needed to all sides so the liner will go up the walls to a height of 3" above the shower curb on all walls and over the curb. Inside and outside corners are necessary and are available for this material, so be sure to figure all corners. Noble Sealant is for Noble to Noble adhering. Each tube provides 75 linear feet (two 1/8" beads required side by side).



- 6 Once you have figured the kits and liner necessary for your Goof Proof Shower, you will need to figure the amount of bedding mud (mixture consist of 1 part Portland cement and 4 parts clean sand) necessary to fill the kits. Using the square footage of your shower floor, multiply by 9.5 lbs. per sq. ft. (i.e. 3 x 5 = 15 sq. ft. x 9.5 lbs. = 143 lbs.). This amount should accommodate all kits.
- 7 After all materials are gathered you will want to watch the instructional DVD a time or two to gain confidence in the steps necessary to complete you Goof Proof Shower. (The DVD is accessible on line 24/7.)

